



# Cargo Box Installation

## Position the box:

1. Place the box where you would like it to go. Make sure it is level, and flat across the back.

## Drill the holes:

2. Using a drill and a 25/64 (or a 3/8 size bit) drill holes in the four corners of the box and mounting surface (tailgate, bedside, etc.).

## Insert the nutserts:

3. Remove the box, and insert the nutserts in the holes in the mounting surface.

## Mount the nutserts:

4. Use the 1/4-20 one-inch bolt, and the 5/16 nut, as a poor man's nutsert tool to mount the 1/4-20 nutsert.



## Tighten the nuts:

5. Tighten down until it is snug or tight within the hole. Hold the 5/16 nut with an open end wrench while using a 7/16" socket to tighten the 1/4" bolt into the hole.

## Install the box:

6. Install the Cargo Box with the supplied 1/4" bolts and large fender washers. Do not over tighten the bolts, too much torque will break the nutserts free.



We'd love to see your gear! Please post a review, and a picture of your install, on the various forums, and on our Instagram, Twitter and Facebook pages.

[www.facebook.com/StrikeForceZebra](http://www.facebook.com/StrikeForceZebra)

[www.twitter.com/strikeforcezebra](http://www.twitter.com/strikeforcezebra)

[www.instagram.com/strikeforcezebra](http://www.instagram.com/strikeforcezebra)

For assistance, please contact us at the email address below

**4722 Bountiful Ridge Dr., Bountiful, UT, 84010**

[www.strikeforcezebra.com](http://www.strikeforcezebra.com) ★ [info@strikeforcezebra.com](mailto:info@strikeforcezebra.com)